

# 471 A Configurable dust collector

## Separators



**43550002**  
Coarse grain separator  
S50, d63/76

**43550005**  
Coarse grain separator  
S50, d51/76

## Silo for separator



**43413026**  
Silo S50 for wall,  
without inlet

## Discharge devices



**43630300**  
Discharge valve  
Linatex d100  
set with reducer  
for flange

**43632001**  
Pneumatic pinch  
valve, DN65  
**43632100**  
Pneumatic pinch  
valve, DN80  
**43632200**  
Pneumatic pinch  
valve, DN100

**43630100**  
Pneumatic dis-  
charge valve


**43630500**  
Pneumatic  
butterfly valve  
\*Control kit  
not included

**43630001**  
Manual dis-  
charge valve

**43630200**  
Counter  
weight dis-  
charge valve

**43630400**  
Manual  
butterfly valve

## Frame



**43751039**  
Adjustable frame with bottom for  
S200 system and stand for S50  
system. Fits with blastpots up to  
680 mm width

**43751040**  
Adjustable frame with bottom  
for S50 system and stand for S50  
system. Fits with blastpots up to  
560 mm width

## Ejector modules



**43051004**  
NE52, with S50 lid and  
2 quick couplings

**43051005**  
NE64, with S50 lid and  
2 quick couplings

**43051006**  
NE74, with S50 lid and  
2 quick couplings

## Filter module




**43160101**  
NCF 1.6, S50, with  
candle filter

## Hose



**40377090**  
Hose PU12, ø63 mm  
L=2,5 m

## Silo for bagholder



**43420027**  
Silo S50 with plastic  
fasteners. Inlet ø76,  
for bagholder

## Silo for container



**43420026**  
Silo S50 with plastic  
fasteners. Inlet ø76,  
for container

## Bagholders for silo



**43640001**  
Bagholder S50

**43640003**  
Bagholder S50 for  
pneumatic discharge  
valve

## Container for silo



**43334001**  
Container S50, with  
eccentric fasteners  
67 liters

**43332001**  
Container S50, with  
eccentric fasteners  
47 liters

## Accessories for bagholders



**43650104**  
Plastic bag  
25 pcs.

**43630500**  
Pneumatic  
butterfly valve  
\*Control kit  
not included

**43630001**  
Manual dis-  
charge valve

**43630200**  
Counter  
weight dis-  
charge valve

**43630400**  
Manual  
butterfly valve

**43630100**  
Pneumatic dis-  
charge valve  
Only for bagholder  
43640003