Additional Information

For this nozzle design it is mandatory with a tail pipe stop mounted on the exhaust pipe to ensure a correct nozzle disconnection from the exhaust pipe.

The tail pipe stop should be assembled according to the instruction enclosed in the package of the tail pipe stop.



www.nederman.com

Nederman is represented in:

Australia, Austria, Bahrain, Belgium, Brazil, Bulgaria, Canada, China, the Czech Republic, Cyprus, Denmark, Egypt, Estonia, Finland, France, Germany, Greece, Hong Kong, Hungary, Iceland, India, Iran, Ireland, Italy, Japan, Korea, Latvia, Lithuania, Malaysia, the Netherlands, Norway, Philippines, Poland, Portugal, Romania, Russia, Saudi Arabia, Serbia & Montenegro, Singapore, Slovenia, South Africa, Spain, Sweden, Switzerland, Taiwan R.O.C., Thailand, Tur key, United Arab Emirates, United Kingdom, USA.